

ROLL BAR TOOL MOUNTS

Fits Roll Bars, Roof Racks or Bull Bars of 1", 1 1/2", 1 3/4", or 2" Diameter (25, 40, 47 or 50mm)

Contents:

2 each 2" (50mm) Roll Bar Mounts
2 each 1 3/4" (47mm) snap-in inserts
2 each 1 1/2" (40mm) snap-in inserts
2 each 1" (25mm) snap-in inserts
All the necessary stainless steel hardware

The following QUICK FIST Clamps can be used on the Roll Bar Tool Mounts:

- Original QUICK FIST Clamps (10010) • SUPER QUICK FIST Clamps (20020) • MINI QUICK FIST Clamps (30050)
- 3" QUICK FIST Clamps (50050)
- QUICK FIST RATCHET Clamps (70070)

DO NOT INSTALL ON ANY PART OF A ROLL BAR THAT IS HIGHER THAN THE BACK OF THE FRONT SEAT. This minimizes life threatening objects from hitting an occupant in a roll-over. Safe working load for two QUICK FIST Clamps is 50 lbs. (23 kilos). Safe working load for two SUPER QUICK FIST Clamps is 100 lbs. (45 kilos).

Installation:

It is best to attach the QUICK FIST Roll Bar Clamps as low as possible on your roll bar. Bottles like Fire Extinguishers or air tanks should be mounted so the base is on the floor or deck of the vehicle.

1. If needed, select the snap-in size that matches the size of the roll bar and insert.

2. Insert the rubber piece into the bottom of the Roll Bar Clamp. Put the Roll Bar Clamp around the bar. Insert two square nuts into the back of the clamp and then insert two socket head bolts into the matching holes and tighten lightly. Insert the two other socket head bolts into the other side of the Roll Bar Clamp and tighten lightly into the square nuts. Locate clamp where desired and then tighten all four bolts.

 3. Mount the QUICK FIST clamp (If the clamp has only one hole, use the center hole). Use the 7/8" bolt, nut, and washers provided (washer and bolt go inside the QUICK FIST Clamp). Do not overtighten.

 4. Repeat on other side.
- Remember to periodically check that bolts are tight.
USE PRODUCT #90060 FOR INSTALLING Hi-Lift® JACKS ON ROLL BARS, ROOF RACKS OR BULL BARS

